1. Notice: After inserted the Bluetooth Module on BMS, please close the battery pack case to check the bluetooth signal, the signal should be above -75 before sealing the battery pack, otherwise, there may be some dropout in use due to the bad bluetooth signal

2. After opening this app, please authorize the GPS to the APP all the time instead of during the use of the APP, When using the APP, you need to turn on the phone's GPS, Otherwise it may not connect

3.For the remaining mileage, the remaining mileage shall be displayed correctly only when the APP is always open and cannot be switched out during cycling

Open the mobile phone browser to sacan the QR code,and click "Identify the two-dimensional code in the picture".



Click “Parameter setting” to set up current product protection information



Click” function setting” to set up current app functions, generally you don’t have to set up it, just keep the default setting



Click “app setting”, you can set up the driving mode , monitoring mode, and you can also change the password here